

MRF Mixing Instructions

Dosage 40ml of Gibco MRF per 20kg bag of cement

1. Disperse Gibco MRF in water before adding sand and cement
2. If using Gibco as a plasticizer only, or if you still want to use lime then reduce dosage by 50% i.e 20ml per 20kg bag of cement
3. For sharp hungry washed sands increase dosage to 60ml.
4. Add Portland cement, sand and water until desired consistency.
5. If mixed with a conventional mortar mixer mix for a minimum of 5 minutes and no longer than 6 minutes.
6. If mixed in smaller portions with a drill paddle mixer, mix only for a period of 30 – 40 seconds.

Important note: Excessive mixing & overdosing of product can cause aeration problems, and may affect the strength of the mortar.